

KEY

- 1 Root-tex 30 geotextile
- 2 200mm deep ProtectaWeb tree root protection system infilled with 4/20 Clean angular Stone to BS EN 13242 / EN 12620
- 3 Root-tex 10 separation geotextile
- 4 Treated timber edging (Or other edging detail acceptable)
- 5 Block Paving with sand bed to Engineers Specification
- 6 Soil graded to edging (if required)
- 7 Existing tree

NOTE

Remove top 50mm of vegetation by hand.

More may be removed at the descretion of your Tree Officer.

